

1. Bowl lock nut
2. Lock nut gasket
3. Main nozzle retainer spring
4. Main nozzle
5. Bowl
6. Bowl cover gasket
7. Float valve seat
8. Float valve seat gasket
9. Float lever pin
10. Float
11. Float lever
12. Float valve
14. Throttle lever
15. Throttle lever arm
16. Throttle shaft spring
17. Throttle shaft screw (2)
18. Throttle disc
19. Throttle shaft
20. Low speed needle valve
21. High speed needle valve
22. Needle valve lever screw
23. Needle valve lever
24. Needle valve lever spring
25. Lever spring collar
27. Air intake shaft stop
28. Friction ball
29. Friction spring
30. Air intake disc screw (2)
31. Air intake disc
32. Air intake shaft
33. Idle hole body plug
34. Idle passage plug screw (3)
35. Fixed Jet
36. Throttle shaft bushing (2)
37. Venturi

13. Throttle stop lock screw

26. Air intake shaft nut and washer